the firmware (U18) on DT-4096 board.



Version: 1.00 **Date:** 13-May-2022

Application Note

Procedure to update the firmware (U18) on DT-4096 board.

the firmware (U18) on DT-4096 board.



Version: 1.00 Date: 13-May-2022

Revision History

Date	Rev No.	Page	Summary
13 May 2022	1.00	All	First issued

the firmware (U18) on DT-4096 board.



Version: 1.00 **Date:** 13-May-2022



The DT-4096 controller is an easy to use high quality HDMI & Displayport input interface for LCD panels up to 4096x2160 resolution.

One of the features of the DT-4096 is the ability to update its firmware as detailed in this Application Note.

IMPORTANT NOTE: Firmware Upgrading must only be done by suitably qualified professionals or technicians. Digital View is not responsible for damage or injury caused by the firmware upgrade procedure.

2 Firmware Upgrade procedure

DT-4096 firmware upgrade can be done using a dedicated USB programming interface available from DigitalView this connects to the HDMI input on the DT-4096.

Before upgrading the firmware, please prepare the following items:

- PC with Windows 7 / 10 / 11 operating system installed.
- The relevant firmware upgrade program RTD Customer Tool V3.5 or up revision, this is available from your local Digital View office.
- External programming board (P/N 411102600-3)
- HDMI cable
- USB cable (one side in type-A connected to PC, and another side in mini-USB connected to programming board)
- Firmware bin file
- DT-4096 to be upgraded needs to be fully connected with power and a display. This
 should be a bench or assembly setup and care must be taken to avoid short circuits or
 electrical shock. Digital View does not accept responsibility for damage caused
 during a firmware upgrade procedure care must be exercised


the firmware (U18) on DT-4096 board.



Version: 1.00 Date: 13-May-2022

Firmware update procedure:

<Step 1> : Connect HDMI cable to External programmable board (P/N 411102600-3) and DT-4096. Use a USB cable to link up the PC and the External programming board. See the diagram below:



<Step 2> Power up the DT-4096 controller.


<Step 3> On PC, run the "RTDTool.exe" to start "RTD Customer Tool" firmware upgrade program

the firmware (U18) on DT-4096 board.



Version: 1.00 **Date:** 13-May-2022

<Step 4> For first time running the "RTD Customer Tool" program, please install USB driver by choosing "Communication Option" \rightarrow press "Install" button in driver section as depicted in the image shown below.




Application Note: Procedure to update the firmware (U18)



Version: 1.00 **Date:** 13-May-2022

<Step 5> In "RTD Customer Tool" program, its window is shown as follows and make sure USB connection is ready (USB status shows a green tick icon). If the USB status shows a red cross icon, please unplug and plug the USB cable of programming board to re-initialize the USB connection.

on DT-4096 board.




Application Note: Procedure to update the firmware (U18) on DT-4096 board.




Version: 1.00 **Date:** 13-May-2022

Step 5> Tick the Bank box '0'
Option Debug message Communication Option
Access method: RealtekUSB Scaler: RTD2795T-CG Stop Run Reset
Bank Path Last modified time: 2022/03/31 15:59:14
CRC Len Refresh
O D:working\DT-4096\working\Output\RE6449\DT-4096_V1.00.00.02.bin
C4 65536
C4 65536

<Step 6>: Press "..." button beside Bank 0 row to select the firmware bin file to be downloaded.



<Step 7> : Press "lightning" button to start firmware download process



Application Note: Procedure to update the firmware (U18)




Version: 1.00 **Date:** 13-May-2022

<Step 8> : Firmware update is in progress.....

If there is any failure during firmware download process and it is stop, please press

on DT-4096 board.

"lightning" button again to re-start firmware download process




Application Note: Procedure to update the firmware (U18)



Version: 1.00 **Date:** 13-May-2022

<Step 9> : If the firmware download process is completed successfully, the program displays "O.K." message as shown below.

on DT-4096 board.



<Step 10> : Quit the "RTD Customer Tool" program.

-END-

the firmware (U18) on DT-4096 board.



Version: 1.00 **Date**: 13-May-2022

CONTACT DETAILS

USA: Digital View Inc.

18440 Technology Drive

Building 130

Morgan Hill, CA 95037

Sales: <u>ussales@digitalview.com</u>

EUROPE: Digital View Ltd.

The Lake House Knebworth Park Herts, SG3 6PY

UK

Tel: (44) (0)20 7631 2150 Fax: (44) (0)20 7631 2156

Sales: <u>uksales@digitalview.com</u>

ASIA: Digital View Ltd.

Units 705-708 7/F Texwood Plaza 6 How Ming Street

Kwun Tong Hong Kong

Tel: (852) 28613615 Fax: (852) 25202987

Sales: hksales@digitalview.com

The content subject to change without notice

Application Note – Procedure to update firmware (U18) on DT-4096 © Digital View Ltd 2022